

## Programação “Wizard” Audiovox PPC-6600

1 - Para programar , seguir os seguintes passos:


1.1 – “Phone On”:



1.2 – Tools:



1.3 – Activation Wizard:



1.4 – Next:



## 1.5 – Next:

Activation 1 EV 10:48

If you have already set up your wireless account, please select Next to skip this screen.

To activate your wireless device, please call your wireless service provider.

Additional notes:

You should have the following information readily available:

- Your billing address
- Your Social Security number or Tax ID number
- Your driver's license number
- Pen and paper to write down your new information

< Back   **Next >**   Cancel

## 1.6 – ESN (Electronic Serial Number): “000000”

Activation 1 EV 10:49

When the service representative asks for the Electronic Serial Number (ESN), please provide the following number.

3606BEDB

When the service representative provides you with the activation code, please enter the number below:

**000000**

< Back   Next >   Cancel

### 1.7 – Next:

Activation |Viz| 10:50

When the service representative asks for the Electronic Serial Number (ESN), please provide the following number.

3606BEDB

When the service representative provides you with the activation code, please enter the number below:

000000

< Back   **Next >**   Cancel

### 1.8 – Phone Number: “Fornecido pela Vivo”

Activation |Viz| 10:54

Please enter the phone number given to you by your wireless service provider.


111   111   1111

Please enter the MSID given to you by your wireless service provider.

0000000000

< Back   Next >   Cancel

## 1.9 – MSID: “Repetir o Phone Number”



Activation Wizard 11:21 ok

Please enter the phone number given to you by your wireless service provider.

111 111 1111

Please enter the MSID given to you by your wireless service provider.

1111111111

< Back Next > Cancel

Keyboard icon

Detailed description: This is a screenshot of a mobile phone's activation wizard. The top status bar shows 'Activation Wizard', signal strength, Wi-Fi, and the time '11:21' with an 'ok' button. The main screen prompts the user to enter their phone number, which is shown as '111 111 1111'. Below that, it prompts for the MSID, with a text box containing '1111111111' circled in red. At the bottom, there are three buttons: '< Back', 'Next >', and 'Cancel'. A keyboard icon is visible in the bottom right corner.

## 1.10 – Next:



Activation Wizard 11:21 ok

Please enter the phone number given to you by your wireless service provider.

111 111 1111

Please enter the MSID given to you by your wireless service provider.


1111111111

< Back Next > Cancel


Keyboard icon

Detailed description: This is a screenshot of the same mobile phone activation wizard as in 1.9. The status bar and prompts are identical. The MSID text box still contains '1111111111'. In this screenshot, the 'Next >' button at the bottom is circled in red, indicating the next step in the process. The keyboard icon is also present in the bottom right corner.


### 1.11 – SID: “Fornecido pela Vivo”



### 1.12 – Finish:



### 1.13 – Save: “Yes”



### 1.14 – Reset Device: “Ok”

